

How to change VAC machine canister

Press the On/Off button on the touch screen to stop therapy.



To remove the canister:

Press down on the canister latch release.

Pull the canister directly away from the therapy unit.



To install the new canister:

Slide the canister over the canister latch guide (do not twist or turn the canister).

Press the canister firmly onto the therapy unit until an audible click is heard.

If the canister is securely installed, the canister cannot be removed by gently pulling the canister directly away from the unit.



Press the On/Off button on the touch screen to restart therapy.

